



Terwin 2000 series Extrusion Pressure Transducers

Handling procedures to give maximum life.

All melt transducers, regardless of who manufactures them, should be handled with great care and it is important that they are installed into the extruder adhering to the manufacturer's installation procedures (see enclosure giving Terwin recommendations).

During the manufacture and shipping of our transducers, every precaution is taken to ensure that our products reach you in perfect condition. Each transducer is manufactured to our customer specifications with the appropriate pressure range, effective stem length, thread size, electrical connector, thermocouple output and any other options that may be called for.

Prior to final calibration, each transducer is cycled extensively on a pressure/temperature test rig at 20% over the normal range of the transducer i.e., a 0 – 10,000 psi transducer will be cycled at 12,000 psi at a temperature of 200°C / 392°F. This procedure is carried out to ensure that transducer is both mechanically and thermally stable when put into service.

Further more, during final calibration, each transducer is subject to an overload pressure of up to twice the full range pressure or 22,500 psi, which ever is less. This is to ensure that the transducer can withstand the normal running or occasional peak pressures without damage to the diaphragm or strain gage assembly that is built into the electrical termination head. Even after this overload, it should be noted that the diaphragm, which is in contact with the polymer remains flat.

During final inspection, the transducer is fitted with a plastic thread/diaphragm protection cap and a square rubber gasket that is fitted over the electrical termination head. This last item prevents the transducer rolling off a work station prior to installation, which if allowed to happen, could result in severe mechanical shock and damage to the strain gage assembly.

Additionally, each transducer has attached to it a Cautionary Installation Label giving recommended procedures. This is further supported with the provision of an Installation/Calibration Instruction Manual plus a Final Assembly Test Data Sheet.

Figure 1 on the following page illustrates all items provided at time of dispatch.

Figure 1



The protective cap and gasket should be left on the transducer until such time that the mounting port on the extruder has been prepared for use using a Transducer Mounting Hole Cleaning Tool Kit. Installation of transducers into ports that are contaminated with old material is one of the primary causes of failure as hardened plastics can tear the diaphragm and this means that the transducer is rendered useless.

The cleaning kit will help ensure that the 45° sealing face is clean, the hole allowing the tip of the transducer to pass freely into the extruder is clear and the threads are free from debris. Please refer to the attachment to this article, which illustrates a cleaning kit.

Each kit contains a ½-20UNF-2A four-fluted bottoming tap, cleaning drill with guide and handle, gage blanking plug, allen wrench and one pot of Dykem Blue.

The suggested procedures for using these kits are as follows:

1. Clean the port threads using the four-fluted bottoming tap until the threads are clean.
2. With the cleaning drill inserted into the guide sleeve and handle attached, screw the guide sleeve into the extruder mounting port – finger tight only. Now in a clockwise direction, push and turn the cleaning drill so that any old material is removed from the 45° sealing face and transducer tip mounting hole. The procedure may have to be carried out several times until the tool is clean when finally removed.

3. Apply a coating of Dykem Blue on the gauge blanking plug over the whole area below the threads. Screw the plug into the extruder until it bottoms out on the 45° face. Remove the plug and inspect – only the 45° face should have had any blueing removed. If there is evidence that blueing has been removed from other surfaces, this may mean that the port has not been cleaned correctly or the port has not been machined properly.
4. Having ensured that the port is now fit for purpose, remove the plastic protective cap from the transducer threads and screw this into the extruder port. If the threads on the port are clean, it should be possible to screw the transducer in by hand until it bottoms out on the 45° face. Now using a torque wrench with a 7/8" crow foot, torque the transducer into the extruder to **20ft.lbs maximum**.

Note: Exceeding the recommended mounting torque could result in damage to the body of the transducer and internal tubes, thus rendering the transducer useless.

5. Next, remove the protective rubber gasket from the electrical termination head, connect the appropriate cable assembly to the transducer and the installation is now complete. Now, the transducer must be calibrated through the measuring instrument as follows:
6. Without running the extruder screw, apply temperature to the extruder until the desired settings are achieved. Upon reaching temperature, allow 20 minutes for the temperature to stabilize around the transducer and then adjust the zero on your pressure indicator/signal conditioner and then check and adjust the calibration at 80% of the full range i.e., on a transducer with a range of 1,500 psi the cal figure will be 1,200 psi. If there are large adjustments to be made, it may be necessary to repeat the calibration procedure once more. Calibration is now complete and the extruder may now be started following your standard operating procedures.

Note: Under no circumstances, must the extruder be run until all zones have reached the desired polymer extrusion temperature, as another primary cause of transducer failure is cold starts. Not only will a cold start damage the transducer but this can also result in severe damage to the extruder.

EXTRUDER START UP AND SHUT DOWN

On many extruders, manual controls are provided for starting/stopping the extruder drive by means of delivering an analog signal to the drive circuitry. It has been found that if the extruder drive is subject to a fast start or closure by cranking up the control potentiometer, this will in effect produce a very fast pressure peak that is almost impossible to detect, unless the melt pressure transducer is connected to an instrument such as a UV recorder. However, this fast rising pressure peak is sufficient to destroy the pressure transducer strain gage assembly and it is therefore recommended that fast starts are avoided.

REMOVAL OF TRANSDUCERS FROM EXTRUDERS

Under no circumstances must transducers be removed from extruders whilst the machine is running or if there is pressure in the barrel, as this may lead to personal injury. However, it is important that no attempt should be made to remove a transducer from the extruder whilst polymer in the machine is cold, as it is likely that the plastic material will have adhered to the diaphragm during cooling and this will lead to the diaphragm being damaged. Ideally, the transducer should be removed from the extruder when the polymer is close to the recommended extrusion temperature.

As procedures and materials used in the cleaning of extruders can damage the transducer diaphragm, it is important that transducers are removed from the machine before cleaning the extruder barrel.

CLEANING OF TRANSDUCERS

Do not use wire brushes or knives to clean solidified polymers from the transducer tip, as irreparable damage may be inflicted to the diaphragm. To prevent this from happening, heat the probe to the melt temperature (**do not exceed 450°C / 842°F**) and remove the polymer with a soft clean cloth. Any residue of material left in the threads can be removed by simply cleaning with a ½-20UNF-2B die and then finally, use an aerosol mechanical cleaner to ensure that all debris is washed away.

TRANSDUCER CALIBRATION.

Upon initial installation, transducers should be calibrated through the pressure indicator/signal conditioner as detailed in page 3 paragraph 6. This procedure should also be carried out in the event of a change in the process temperature, or if the transducer is removed and reinstalled into the extruder, as the zero output of a transducer will change when it is torqued into the machine.

In the event of calibration difficulties, which may be caused by damage to the transducer, cable assembly or process indicator, it is recommended that the cable assembly and indicator be checked with a transducer simulator (see enclosed data sheet), in order that the fault can be isolated to the relative component. This device allows you to connect your process indicator via your normal cable assembly to the simulator and perform basic functional checks. Whilst the simulator has reasonably good accuracy, it should be noted that it is not a calibration standard.

Terwin Instruments Ltd



**Manufacturers Of Industrial Pressure / Temperature
Sensors & Instrumentation**